

Prop Guard Cage Fabrication

Note, carbon dust is very harmful if inhaled, use a dust removal system when cutting, sanding, or grinding carbon parts. Also fumes from CA and epoxies are harmful, so also use a ventilation system with those adhesives.

For the epoxy, slow cure is stronger, 5 minute cure is okay. DP460NS is a high performance epoxy that would be ideal.

For the CA glues Bob Smith brand thin and medium viscosity glues are good. Regular type is best, but foam safe is okay. Also the foam safe 'Insta Set Accelerator' is good for kicking off the glue, particularly when the kevlar thread is coated with CA glue.

Carbon tube prep

Hole is 0.0591" diameter, centered 0.400" from end. Perpendicular to slot. Chamfer/round over this end. Hole needs to be centered. Large tube is 0.257" diameter, cut to 6.400" overall length, +0/-.03". 4 pieces per assembly. Slot is 0.065" wide, and 0.630" long. Perpendicular to hole on opposite end. Slot needs to be centered. Small Short tube is 0.155" diameter, cut to 1.930" overall length, +/.02" 32 pieces per assembly. Chamfer/round over the edges. Holes at both ends are 0.0591" diameter, **Small Long tube** is 0.155" diameter, cut to centered 0.230" from ends. Holes need to be


0

11.300" overall length, +/.02" 8 pieces per

assembly. Chamfer/round over the edges.

well centered, and parallel to each other.


Collar prep




Drill out the large hole collars with a nominal .257" diameter drill, or to fit snug on the large tubes. 4 per assembly.


Drill out the small hole collars with a nominal .156" diameter drill, or to fit snug on the small tubes. 16 per assembly.






Use the motor mount to check the slots in the joiner, remove any residue from printing.













This completes the motor mount assembly procedure. Make 4 of these.




















To drill the hole in the large tube, use a .0591" drill in a drill press. Preferably with a good vise and X-Y table that allows carefull positioning. First step is to make sure the drill will be centered on the tube.






With the tube in the vise, clamp down the tube carefully, making sure the guard piece is perpendicular to the drill bit within a few degrees.





Drill the hole, centered at 0.400" from the end of the tube, drill the hole all the way through the tube.







Chamfer/round over the edges to aid in the pressing operations. This image does not show much chamfering, more would be better.






Setup the press centered over the spacer plate. Hold the short tube, and press in until the tube bottoms out. Visually check that the tube is vertical. Start with the upper guard piece.








It should look like this when done, the friction should hold them firmly in place.

Flip over that assembly, and take a lower guard piece and alight the first two tubes, and get ready to press in the first one.





Press in the first tube, note that this will cause the guard pieces to bend a bit, that's okay.




Press in all the tubes in the lower guard piece. Because of the bending, you can go back and re-press them all. This may or may not be necessary depending on your setup and technique.















Then bond all of the tubes in place, top and bottom on all joints. Medium thickness CA glue is probably easiest. Epoxy is fine also. A syringe is probably good to use for epoxy.





























If the screw is difficult to start, grind a point onto one.







After the collar is cured, wind the entire length of the large tube with kevlar thread, up and down the length, and several wraps where it joins the guard assembly as shown. Then coat with thin CA glue all over the kevlar thread. Wipe the CA on with a paper towel carefully and quickly. Epoxy can be added to the joint afterwards for extra strength.











Check that the joiner is completely seated on the guard piece.





Glue the joiner onto the guard with CA glue or epoxy, be careful not to let glue harden inside the large hole. Drill out afterwards if necessary.




After installing all 4 joiners onto the guard assembly, this completes the guard assembly procedure. Make 4 of these.













Clamp the tube in the vise to drill the other end, same as the first one, but also visually check that the drill in the drill press is parallel to the drill/rod sticking up from the far end of the tube.


Then drill the second hole all the way through.















end of the tube.









This completes the steps to build all of the prop guard sub-assemblies.

To install the prop guard cage onto the aircraft for the first time:

- 1. Install the new motor mount piece under the motor, note notch goes up. Use long motor mounting screws, not the factory supplied DJI ones. Do not tighten down firmly, allow the motor mount to move a bit, they will be tightened at the end.
- 2. Take two of the prop guards, and install 4 of the long tubes into each of them.
- 3. Slide the two prop guards with the long tubes on the motor mounts on opposite sides of the vehicle, but do not insert all the way, leave about a ¼" gap.
- 4. Install the other 2 prop guards, again leaving around a ¼" gap.
- 5. Flex the assembly as necessary, and insert the long tubes into all of the prop guards, so all of the long tubes are inserted, at least a little bit.
- 6. Insert the prop guards into the motor mounts further, and then insert the long tubes into the prop guards a bit further, and keep going around the vehicle doing this until everything is fitted tightly.
- 7. Install all of the small screws, there are 20 total.
- 8. Then tighten the 4 screws under each motor.
- 9. This completes the first installation process.
- 10. To remove the prop guard cage, do the same process in reverse, but don't touch the motor mounting screws. Just remove the 20 tiny screws.

